

FIG. 1




FIG. 2

Initialize Configuration ~ 200

eth1 pinging target IP address ~ 210

eth1 goes down ~ 240

PPP comes up, sends route update to remote peer
GOTO FIG. 3 ~ 250

FAILOVER ENABLED? ~ 265

MAINTAIN PPP Connection ~ 267

can it reach the target? ~ 270
No AT MAX NO. OF RETRIES

PPP checks target ~ 270

can it reach target? ~ 280

PPP stay up, keep checking target ~ 290

PINGING STOPS TEMPORARILY ~ 230


PPP goes down ~ 300

eth1 comes up, sends route update to remote peer ~ 310

FIG. 3

Step 250, FIG. 3

FIG. 4



GO TO STEP 270, FIG. 3